



# XUVER REVIT EXPORTER




## OPEN REVIT

After install Revit will run the Xuver application by default. Your screen will display a message informing you about a new plugin. Select **Always Load**.



## LOCATION



Select **Add-Ins** in the Revit Menu bar. The menu will display the XUVER REVIT EXPORTER icon.



## EXPORT PROJECT

1. Go to 3D view of the project
2. Click on Xuver Export icon
3. Choose name and place to save the file
4. Click **Save**

The scene will be exported to .xr file. It will finish when in a window will say Finished and you will be able to click OK.



## UPLOAD

To visualize your model in the Viewer, Login to your Xuver Account and upload your .xr file on the platform.